



As a first step, please remove the protective foil from all parts before assembly (the parts are coated from BOTH sides).

Begin assembly of the case by putting the front panel 3 on a flat surface (i.e. table). Connect the side panels 2 and the top to the front panel as illustrated in the diagram on the right side. Now place the black back-panel 4 on top. Connect all parts of the case using the small countersunk screws and nuts.

Important: Please tighten the screws only lightly.

## Individual Parts :

1 x Set of Screws for Case and Glove-Stand (20 x M2.5 Countersunk Screw, 20 x M2.5 Hexagon Nut)

1 x Set of Screws for the Base (2 x Screw M4 x 6mm, 2 x Sleeve Nut M4 x 7mm)

