




- 1** Please remove the protection foil from all acrylic parts (foil is on both sides).




Firstly stick the connecting parts 23200t on the exterior shelf 23200d and establish a tight connection using the M3 screws and nuts (please fasten the screws only lightly)



Slot the shelves 23200c on the side panel 23200b. Make sure that the round overlaps with the openings are up.




Connect the two readily assembled shelves 23200d, to the side panel 23200b using the small M3 screws and nuts.



Now connect the two exterior side panels 23200e to the shelves and also to the connecting parts.

5



Finally connect the back panel to the sides and shelves. Clamp it firmly with the acrylic pegs. To interconnect several CD Racks or CD and DVD racks sideways please use the longer M3 screws and nuts.

Cleaning instructions :

Please do not use any cleaning agents other than water or special acrylic care products. Many other cleaning agents contain solvents, which can damage the acrylic glass.

If you have any further questions, please contact us by e-mail.

Individual Parts :

24 pcs : Screws and Nuts M3
2 pcs : Connecting-screws and Nuts M3
14 pcs : Acrylic Pegs

23200t
Connecting Parts

