



Golfball display cabinet

Item.No.: 16000

Please remove protection film from the acrylic sheets before assembling.
At first, please connect the shelves to the side panels.

Continue by connecting the back panel to the other parts of the vitrine.
Use the small acrylic wedges to clamp the back panel.



**suitable for wall mounting
or mounting on the floor**

individual parts :

